

Technical Datasheet

TERRAGLOSS CLEAN UV Cleaning Agent G 13/160

29.11.2022

1 / 1

Product description

Washing agent for UV Varnishes for cleaning the coating units, screen rollers, tube systems and varnishing blankets. Rinse the chambered doctor blade for 10 minutes undiluted, then clean it with pure water. For the varnishing blankets and coating plates we recommend a hand cleaning. Dilute cleaner with water 8 : 2. A later rinsing respectively washing with water.

related needs.

Storage instructions

- Shelf-life 12 months

Disclaimer

- All information provided on this product (in this sheet or elsewhere) are made to the best of our knowledge.
- All information are technical quality descriptions, advisory and due to the wide range of materials, production conditions, operations and processes they do not release from own tests and examinations under customer-specific circumstances.
- If an application is intended to be made under different conditions than those specified in this sheet, we only assume liability after having examined the respective different conditions.
- This data sheet does not claim to be complete.
- We reserve the right to change product characteristics due to technical progress, amendment of applicable law and mandatory production-